



Gas Style Griddle

Instructions Manual



FSGGD-0605AFSGGD-0706

Shinelong International Co., Ltd
Web: <http://www.furnotel.cn>
E-mail: info@furnotel.cn
Fax: +86 20-34709972
TEL: +86 20-34709971
Address: 301, Building 1, Tian An Hi-tech Ecological
Park Panyu Avenue Panyu, Guangzhou, China

Thank you for choosing our products, before using of the equipment, please read the Instruction Manual carefully and operates strictly according to the instruction.

This style series product is one of our latest products: its body is made of stainless steel, smooth appearance is designed as European style. It's easily to operate, energy saving and environmentallyfriendly.

1. Normal attention

- A. For the install, first-time use or maintain, you can ask the professional staff to help you.
- B. According to what is requested below when you install or maintain the equipment.
- C. Keep this manual carefully and check it while you need the technical support.
- D. If you have any questions, please contact to the local maintenance center or local distributor!
- E. Turn the gas valve off when you do not use the equipment.
- F. If need to change some parts, you have to contact to the maintenance center or local distributor, they will help to repair the equipment !. Otherwise, it may damage the equipment.
- G. This type of equipment is just used in commercial field; it would take accident if used in other parts.
- H. Do not wash the equipment by water directly.

- I. In order to keep the surface clean, wash the stainless steel appearance regularly to prevent the equipment from being oxidized or damaged by chemical reaction.

Instruction: turning on and off

Rotate the power control knob clockwise to turn the hot plate on, or counterclockwise to turn it off.

The operating indicator lamp to the left of the control knob illuminates the appliance is switched on. It goes dark when the hot plate is turned off.

Turn off the gas. Clean the equipment with a dry cloth after it cools down.

2. Cleaning the unit

Clean stainless steel surfaces with a wet cloth and then wipe dry with a soft cloth.

Stainless steel surfaces can be cleaned with a non-abrasive stainless steel cleaner.

To help prevent soiling, a conditioner for stainless steel is also needed.

3. Frequently asked questions:

A. All repairs should be performed by a trained technician in strict accordance with national and local codes. Any repairs or maintenance performed by unqualified personnel could be dangerous.

B. If power cannot be restored, it may be necessary to call either a Technical Service Department.

4. Basic parameters

Name	Gas style griddle	
Model No.	FSGGD-0605A	FSGGD-0706
Dimension (mm)	550*500*520	730*550*520
Power	5kW	10kW

5 .Operating instructions

5.1 Safety instructions

If there is any abnormal appearance while you are using the equipment, turn off the power switch immediately. Do not use until safety.

5.2Installation

- A. Put the griddle on level ground and ensures a clearance of at least 10cm from both left and the right side against the wall, and at least 20cm from behind.
- B. The supplyinggas pressure must match the specification.Install the allowable gas pipe, gas valve to the equipment.
- C. The gas connection is behind the stove in the rear corner.

Attention:

- A. Please make the gas-loosing test by soap water or professional equipment.(do not use fire to have the test)
- B. Do not destroy the surface or heat plate with solid or sharp objects.
- C. Turn off the gas source after cooking.